

HOW TO FIND YOUR STANDARD JACKET SIZE

Measures A and B will help you select the proper size. Once you find your size, check the jacket length measurements given in the chart against your body to ensure the jacket will not be too long or too short. Our standard jackets are all available in LONG versions for either body length or arm length, or both.

If your measurements don't coincide with the size chart, consider ordering a Custom jacket (see the Custom Jacket Measuring Instructions).

- Before measuring, put on a tight fitting t-shirt. The seams will be a reference to help you measure accurately.
- If you regularly wear supplemental protection **under** your jacket (hard plastron or chest protector, gorget, forearms, etc.) please take your measurments while wearing them over the t-shirt.
- If you do not have a sewing tape-measure available, use a piece of string and measure it against a ruler.
- It is always easiest to measure with someone to help you.

All measurements are in centimeters (1 inch = 2,54 cm)

Standard Sizes (All measurements in cm)										
	00		0		1		2		3	
Your Chest Measure (A)	75-85		85-95		95-105		105-115		115-125	
Your Waist Measure (B)	up to 85		up to 90		up to 100		up to 110		up to 120	
	Normal	Long	Normal	Long	Normal	Long	Normal	Long	Normal	Long
Jacket Front Length (D)	62	64	64	66	66	68	68	70	70	72
Jacket Arm Length (E)	68	70	70	72	72	74	74	76	76	78

